Garmin Forerunner 35 30 0000 00 000 000 000 000

00 000:



1# 黑色 Black



2# 粉色 Pink



3# 水鸭绿 Teal Green



4# 紫色 Purple



5# 橙色 Orange

EASY INSTALL ON / OFF

Quick and simple to install and remove the band.







Accessories

install with Screws and screw driver



